

Basic Remote Control Guide

SYSTEM ON/OFF

Designed to send Power On/Off commands for up to four Components with one button press.

MENU

Displays the Applications Menu.

GUIDE

Displays the program guide listings.

SELECT

Selects the highlighted screen options.

EXIT

Exit from current screen.

DAY

Skip forward or backward a whole day in the program guide.

VOLUME

Raises or lowers the sound level.

ON DEMAND

Provides direct access to On Demand channel.

MUTE

Silences the audio, Press to activate. Press again to restore sound to the previous level.

REWIND

Replays the previous 15 seconds of a program.

My DVR

Displays a list of programs you have recorded, allowing you to select for viewing.

INPUT (TV/VCR)

Selects the video source.

ON-OFF

Opens or closes the Cable Box PIP (Picture-in-Picture) window.

Video Source

Selects the video source.

SWAP

Swaps the contents of the PIP window.

POWER

Allows you to turn your TV, VCR, DVD, AUX, and Cable Box On and Off.

AUX, DVD, TV, CBL

Used to select the component you want to operate and signals remote control activity.

INFO

Displays information about the program currently playing or highlighted in the program guide.

PAGE ▲/▼

Accesses pages above or below the information currently displayed.

CURSOR NAVIGATION PAD (▲, ▼, ◀, ▶)

Navigate to and highlight an item from the on-screen choices.

LAST

Returns to the previously tuned channel.

A, B, C, D

These functions are pre-set by your cable provider.

CHANNEL ▲/▼

Selects the next higher or lower channel.

FAV

Displays favorite channels.

LIVE

Displays live television programming.

VCR/DVD/VOD KEYS

Perform standard VCR and DVD functions when in VCR and DVD mode, and Video-On-Demand functions when in CABLE mode.

NUMBER PAD

Enter numbers to tune channels. Also, make numeric entries on on-screen menus. *NOTE: You can also use the CH ▲/▼ or the guide in alternate ways to tune to channels.*

ASPECT (#)

Change the HD screen viewing aspect.

PIP CH ▲/▼

Selects the next higher or lower channel in the PIP (Picture-in-Picture) window.

MOVE

Moves the PIP (Picture-in-Picture) window o another location on the screen.

